

Parts Included:

494551 Drain  
569034 O-ring



Required Tools:

7/8" Socket

## 494551 Installation Instructions

1. Remove the existing drain using a 7/8" socket.

Note: Care must be used to avoid damaging the plastic liner beside the drain.

2. Before installing the new drain valve assembly, clean and remove all dirt and debris from the bottom of the spill containment. Verify that the o-ring is installed and properly secured.
3. Manually tighten the new drain valve assembly to avoid cross threading. Using a 7/8" socket, torque between 15 ft-lbs and 18 ft-lbs.

**IMPORTANT: Do not use pipe thread sealant compound when installing the drain valve assembly.**

4. Verify that the drain valve opens and closes when pulling up on the chain.
5. Reattach chain to top expanding clamp bolt.

**Emco Wheaton Retail Corp.**

2300 Industrial Park Dr. • Wilson, North Carolina 27893  
252-243-0150 • 252-243-4759 (fax)

p/n 570954  
Rev. A 09/13