

Installation Instructions

1. Remove one of the flange bolts and set aside.



2. Install the A0333-004 Hand Pump and Bracket, lining up the bolt hole in the bottom of the bracket with the bolt hole in the flange as shown.



3. Use a 9/16 socket to tighten the bolt.

