

Parts Included:

571426 Drain Plug
567108 Gasket Seal



Replaces:

493508K & 494118 Drains



493508K
A1004 Slimline, Fatboy
Spill Containment



494118
A1004EVR
Spill Containment

Required Tools:

- Emco Drain Wrench p/n 493820
- Needle Nose Pliers
- Torque Wrench w/30-35 ft-lbs. Setting
- 7/8" Socket
- Ratchet Wrench w/Extension

Installation Instructions

Remove the Existing Drain Valve



1. Remove lid and adapter cap. Use a pair of needle nose pliers to remove both cotter pins, and disassemble the linkage from the top of the drain valve. Remove the drain valve pull chain from the top of the spill containment rim and discard.



2. Remove the filter from the top of the drain valve. Use Emco Drain Wrench 493820 to unscrew the drain valve from the base of the spill containment.

Install the Drain Plug



3. Clean and remove all debris from around the drain path opening and sealing threads.
4. Install the gasket seal in the drain cavity. Screw the drain plug in by hand to avoid cross threading. Use a ratchet and torque wrench with a 7/8" socket and extension to tighten and torque between 30 to 35 ft-lbs.
5. Re-install the fill adapter cap and spill containment lid.

Emco Wheaton Retail Corporation

2300 Industrial Park Dr. · Wilson, NC 27893
252-243-0150 · 252-243-4759 (fax)

p/n 571951
Rev. B 04/16