

## PHASE | EVR SYSTEM INSTALLATION AND MAINTENANCE TOOLS





All tool bits are fully interchangeable with A0081-001D Drive Shaft and A0081-001X Cross Bar

Also available:

A0081-001A Extension

A0081-110Q Quick Release Pin

A0081-001B Adapter Wrench Bit \_\_\_\_\_



Installation and removal of:

- Models A0030-014, A0030-124S & A0076-124S Adapters
- Model 494096 Riser Seal



A0081-001HB Spill Containment Wrench Bit \_\_\_\_\_



A0081-001LB Riser Seal Wrench Bit .

Installation and removal of:

 Model A1004EVR Series **Spill Containers** (Multiport or Direct Bury)





Installation and removal of:

- Model 494096 Riser Seal Center Insert
- Models A0030-024 & A0030-024A **Adapters**







## PHASE | EVR SYSTEM INSTALLATION AND MAINTENANCE TOOLS



493820 Drain Valve Wrench



Installation and removal of:

Drain Valve
 Part Number 494118



494240
Swivel Adapter Torque Test Wrench\_\_\_\_\_



Verification of static torque for:

 Models A10030-124S and A0076-124S per CARB test procedure TP-201.IB



566675 A1100EVR Collar Drill Fixture



Drilling of collar mounting holes:

• Model A1100EVR Overfill Valve

