

A0028-001 Riser Lock

Installation Instructions

- Loosen all riser lock mounting bolts and lock nuts. Slip the riser lock assembly over the riser pipe, letting it drop to the top of the tank.
- Place gravel pan over the riser pipe and on top of the riser lock.
- 3. Thread on spill containment.
- Lift gravel pan so that the bottom is flush with bottom of gravel guard.
 Secure in place with duct tape as shown in photo.
- Raise the riser lock so that it is positioned midway from the top of the tank to the bottom of the spill containment. Tighten each bolt and lock nut to lock in place.

