


## A0097-005 Fill Adapter Cap

## INSTALLATION INSTRUCTIONS



1. Locate the fill adapter cap over the swivel fill adapter and lock into place by pressing down on the handle.

## PREVENTIVE MAINTENANCE

1. Annually verify that the gasket seal is properly secured and free of tears. If the fill adapter cap fails to comply, replace with new.

## PERFORMANCE SPECIFICATIONS

This component was factory tested to, and met, the following specifications.

1. Meets ARB Cam and Groove Specifications.

IMPORTANT: Leave these <u>installation instructions</u>, <u>product warranty</u> <u>registration card</u> and the <u>warranty tag</u> with the station owner and/or operator.