

# A0099-001TEST Vapor Test Cap

The A0099-001TEST Vapor Test Cap is used when performing a pressure decay test. The cap incorporates the same features as the A0099-002 Vapor Cap. The extended tube underneath the cap opens the poppet on the vapor adapter. Pressure is injected through the Schrader valve, and a gauge can be connected to the barbed fitting.

<b>Model No.</b>	<b>Cam &amp; Groove</b>	<b>Lbs.</b>
A0099-001TEST	4"	1.4.

570739 Replacement Gasket

